

PRECISION PERFORMANCE PRODUCTS

20122 STATE RD, CERRITOS 90703
PHONE 562/402-1108 (FAX 562/402-4383)

www.precisionperformance.com

KWIK SHIFT I & II ELECTRICAL SCHEMATIC

KWIK SHIFT 1 WITH TRANS BRAKE SWITCH, THE TYPICAL BASIC SCHEMATIC IS TO USE A SIMPLE PUSH BUTTON STARTER SWITCH, WITH ACCESS TO BOTH TERMINALS TO BE CONNECTED AS SHOWN IN **FIG. 1**

KWIK SHIFT I & II WITHOUT TRANS BRAKE SWITCH IF YOU PLAN TO USE THE STOCK KEY FOR A STARTER SWITCH OR AN AFTER MARKET ELECTRICAL PANEL, YOU WILL NEED TO FOLLOW **FIG. 2**

NOTE: WHEN USING **KWIK SHIFT I** AND THE INTERNAL TRANS-BRAKE SWITCH AND STOCK KEY STARTER SWITCH OR AN AFTER MARKET ELECTRICAL PANEL USE THE SCHEMATIC AS SHOWN ON PAGE 2 **FIG. 3**

FIG. 1





FIG. 2